



**(260)-422-8823**

## **OPERATING INSTRUCTIONS FOR MODEL 3000 SECURITY SYSTEM**

To clear a mistake: Press #

To arm the system when no one is staying inside the premises:

Enter the combination

The exit delay permits you to exit the delayed door. The system senses a delayed door was opened/closed and automatically activated the interior detection devices.

To bypass a detection device:

Press \*1 (zones to be bypassed - ex: 04 for zone 4, 05 for zone 5)

Press # and the combination

To arm the perimeter while at home and later arm the interior:

Enter the combination (activates perimeter)

Press \*1 (activates interior devices)

To reset the panic system:

Enter the combination

To reset the fire alarm:

- A) Before 30 seconds have elapsed - put in code to stop siren, Then press \*4 (hold the 4 button for about 5 seconds) to reset The detectors.
- B) After 30 seconds have elapsed - put in code to stop siren, then press \*4 (hold the 4 button for about 5 seconds) to reset detectors, then call 422-8823 to cancel the fire dispatch.

To review an alarm event in memory (memory light on) :

Press \*3 (the zone or zones violated will blink displaying any violated zones.) Then press 9 for alarm activity before current alarm and 9 again for the alarm before that one. Memory will hold three alarm events. Press # to return to normal. The memory light may stay on until the system is armed again.

To review a trouble condition (trouble light on and system beeping every 10 seconds):

Press \*2 - a zone light will illuminate indicating the type of trouble.  
Then press # to return to normal

- Zone light 1 - Low battery
- 2 - Loss of AC power
- 3 - Day zone trouble
- 4 - Phone line trouble
- 5 - Unsuccessful communication
- 6 - Bell trouble
- 7 - Fire trouble
- 8 - Loss of time on internal clock